



Fast And Easy Installation Instructions



Installation Instructions

Step 1: Remove plastic caps.

Step 2: We have included some lengths of tape that should be placed on the bottom of the bed-side protector.

Step 3: Place protector over holes.

Step 4: Insert bolts and tighten.



ATVenture Components Inc

23 Boom Lane, Unit E
Atholville, NB, Canada, E3N 4E8
www.atv-bumpers.com

F-7.5. 1-02-00

ATVenture™
components inc.

Approval Date: _____
Initial: _____
Rev: _____
